







ASSEMBLY INSTRUCTIONS
MODEL: 17851


Before assembly, please remove all parts from the carton, verifying that you have the correct quantities, and read all the instructions.

IN THE CARTON:


Ax1		
Bx1		
Cx1		
Dx5		
Ex1		
Fx1		

INSTRUCTIONS:


①




②



③



④



▲ ATTENTION
 If any parts are missing, broken, damaged or worn, stop use of product until repairs have been made using factory authorized parts.
 Failure to follow these warnings may result in injury.