

# Lock Buying Guide



PL Laminate Standard Key Set



PL Laminate Master



PL Laminate Core Removal



FS Metal Standard Key Set



FS Metal Master Key



FS Metal Core Change Key

## **PL Cabinets**

Cabinet locks are used with laminate DOORS.

#### PI MKFY

PL MASTER KEY, \$36 list PLMKEY is the laminate master key, used to unlock any cabinet. Also used for pedestals



### **PLLOCKCORE**

PL LOCK CORE KIT, \$24 list

PLLOCKCORE replaces your existing lock core. Includes new core, core removal key and 2 new keys. To remove core, cabinet must be unlocked. Also used for pedestals



# **PLLOCKS CABINET** PLLOCKS-SILV CABINET

PL CABINET LOCK ASSEMBLY, \$40 list Complete lock assembly. Replaces your existing cabinet lock assembly.





Silver for use with WHITE laminate products.

# **PL Pedestals**

Pedestal locks are used with laminate DRAWERS.

### **PLMKEY**

PL MASTER KEY, \$36 list PLMKEY is the laminate master key, used to unlock any pedestal. Also used for cabinets



### **PLLOCKCORE**

PL LOCK CORE KIT, \$24 list

PLLOCKCORE replaces your existing lock core. Includes new core, core removal key, and 2 new keys. To remove core, pedestal must be locked. Also used for cabinets



# **PLLOCKS PEDESTAL** PLLOCKS-SILV PEDESTAL

PL PEDESTAL LOCK ASSEMBLY, \$36 list Complete lock assembly. Replaces your existing pedestal lock assembly.







Silver for use with WHITE laminate products.

## **Metal File Drawers**

FS keys and cores used with all metal files.

#### **FSMASTERKEY**

FS MASTER KEY, \$36 list FSMASTERKEY is the metal file master key, used to unlock any metal file.



### **FS-CHANGE KEY**

FS Core Change Key, \$336

FS-CHANGE KEY is the metal file change key, used to remove the lock core on metal files.



### FS-CORE&2KEYS

FS LOCK CORE KIT, \$36

FS-CORE&2KEYS replaces your existing lock core. Includes new core and 2 new keys. To remove core, file must be locked. Requires core change key, FS-CHANGE KEY









# Lock Buying Guide How to order and Frequently asked Questions

# **Locking Products**

All lockable products Storlie Furniture Group sells come with locks and 2 keys. Products will not automatically be keyed alike. For example the PL207 wardrobe ships with a cabinet and pedestal lock, keyed alike.

### **Laminate Locks**

There are two types of laminate locks: locks for a pedestal (drawers) and locks for cabinet (doors).





PLLOCKS CABINET

## **FS Metal Locks**

All metal files use the same style lock.

To remove lock core you must order FS-CHANGE KEY







# **How to Order**

Are you ordering more than 1 item?

NO - your product will arrive with a lock and set of keys, no need to order additional locks.

YES - do you need your items to be keyed alike?

**NO** - your products will arrive keyed separately, no need to order additional locks.

YES - you will need to order additional locks in order to key alike.

## **How to Key Alike**

PL Laminate: Determine how many lock cores you need. You will be ordering lock core kits.

PO should read: PLLOCKCORE (x qty needed), "KEY ALIKE"

FS Metal: Determine how many lock cores you need. FS-CHANGE KEY required to remove core and key alike.

PO should read: FS-CHANGE KEY qty 1, FS-CORE&2KEYS (x qty needed), "KEY ALIKE"

# **Frequently Asked Questions**

### Can I order a replacement key for lock core number X?

Storlie does not sell individual replacement keys. The best solution is to purchase a new lock core or complete lock.

## I have lost my key! I am locked out, help!

The best option is to order a Master Key and replacement lock core. This will allow you to open the lock out and replace with a new secure lock core and set.

## My pedestal is locked and I must urgently open, help!

If you must open your drawer and do not have a master key you can drill out the core. You can then replace the damaged lock with a complete lock kit assembly or lock core.

## I have a lock core change key but can not unlock my drawer?

FS-CHANGE KEY and PL core removal key will not unlock your item. To open you will need the original key or a master key.

PL cabinet lock cores can be removed when the door is locked, but this will not allow you to open the door, you will still need a master key.

### How much does it cost to ship a single lock?

For a quote please email dealerservices@storliecompany.com, include the complete shipping address and specific items needed.